





SKIRMETT WASHROOMS

TRONIC MIFARE



DRAWING





June 2016



RFID CARDS



RFID Classic Mifare 1K/4K (ISO14443A/B)

MANAGEMENT CARD

Function:

Mode Selection (Multi-User / Single User)

Create or Delete Master Cards



MASTER CARD

Function:

Create or Delete User Cards

Inspection Mode and Delete User Card



USER CARD

Function:

Opens or Closes the Lock








SETTING THE FUNCTION

MULTI-USER MODE

USING the MANAGEMENT CARD:

- Press ON BUTTON
- Present CARD twice

Confirmation - Correct Programming
The Reader
Green LED Light Flashes Twice and
2 Short Beeps








SETTING THE FUNCTION

SINGLE-USER MODE

USING the MANAGEMENT CARD:

- Press ON BUTTON
- Present CARD three Times

Confirmation - Correct Programming
The Reader
Green LED Light Flashes 3 Times and
3 Short Beeps







ASSIGNING **NEW** MASTER CARDS

USING the MANAGEMENT CARD & NEW MASTER CARD:

- Press ON BUTTON
- Present MANAGEMENT CARD Once GREEN LED Light Flashes
- Present MASTER CARD for approval Wait 5 seconds for confirmation

Confirmation - Correct Programming
The Reader
Green LED Light Flashes 2 Times and
2 Short Beeps







Up to 5 Master Card can be programmed to each lock


DELETING ALL MASTER CARDS

USING the MANAGEMENT CARD:

- Press ON BUTTON
- Present MANAGEMENT CARD three times
 Wait 5 seconds for confirmation

Confirmation - Correct Programming
The Reader
RED LED Light Flashes 3 Times and
3 Short Beeps

ALL Master Cards have been deleted





INSPECTION MODE


USING the MASTER CARD:

- Press ON BUTTON
- Present MASTER CARD once Wait 5 seconds for confirmation

GREEN LED Light and long beep Lock opens for 30 seconds

After Inspection Time, the lock closes automatically

The USER Card has NOT been deleted




DELETE USER CARD

USING the MASTER CARD:

- Press ON BUTTON
- Present MASTER CARD twice Wait 5 seconds for confirmation

GREEN LED Light and long beep Lock remains opens

The USER Card has been deleted




DELETE ALL USER CARD (ONLY for Single User Mode)

USING the MASTER CARD:

- Press ON BUTTON
- Present MASTER CARD four times
 Wait 5 seconds for confirmation

GREEN LED Light and long beep Lock remains opens

ALL USER Cards for this lock have been deleted




DELETE USER CARD (Multi User Mode)


USING the MASTER CARD:

- Press ON BUTTON
- Present MASTER CARD five times
- Followed by the User Card to be deleted Wait 5 seconds for confirmation

GREEN LED Light and long beep Lock remains opens

USER Card has been deleted





USER CARD - MULTI-USER MODE


USER FUNCTION

TO LOCK:

- PRESS ON Button
- Present USER CARD GREEN Light flashes Bolt is thrown

TO UNLOCK:

- PRESS ON Button
- Present USER CARD GREEN Light flashes Bolt is thrown




USER CARD - SINGLE-USER MODE

USER FUNCTION

TO OPEN:

- PRESS ON Button
- Present USER CARD GREEN Light flashes Bolt is thrown

After 2 seconds the bolt will automatically close



OPTIONS - USER WRIST BAND

Swimming Pool Application



RED or BLUE rubber wrist bands




BATTERY REPLACEMENT

Replacing the 4 x AA Batteries

IMPORTANT:

The battery replacements must be done in less than 5 minutes

The BATPACK must remain connected during the release of the battery tray (to ensure the internal clock does not loose it's programmed time).



TECHNICAL SPECIFICATION

Salt spray test	> 96h
Working temperature	-5°C < > +70°C
Latch force	> 45Kgf
UV Rays	> 10000h
Vibration	10 - 200 Hz 2g
Life test	> 200000 cycles
Electrostatic discharge	8000 V
Battery life	> 70000 cycles











June 2016



PROGRAMMABLE SETTINGS

Various options are available with the TRONIC MIFARE, when using the software management:-

AUTOMATIC OPENING TIME:

The lock will open automatically at a designated time, planned by the installer

- hh: mm
- Mon, Tue, Wed, Thu, Fri, Sat, Sun.
- Working Days
- Two Options: Leave Door Open
 Close Door again (after a pre-planned time)

ACOUSTIC SIGNAL / VOLUME:


- High
- Low
- Off

CODES:

- User
- Master

June 2016

USB Settings Key



Load settings from the computer to the SETTINGS CARD (white)
Present the SETTINGS CARD to the lock
The SETTINGS will automatically be transferred to the lock.

June 2016 30